

SNAPFIL

the

Perfect Fountain Pen



Suggestions

The "safety device" (chain with pin) should be attached to the clothing several inches above the pocket.

The pin and chain is ONLY furnished with Baby Grand and Regular models.

TO FILL—Follow instructions under illustrations.



CUT NO. 1—Remove cap by holding it tight and turning holder to left.



CUT NO. 2—Raise trigger to position shown.



CUT NO. 3—Submerge pen point clear to rubber flange of holder and press on trigger.

WHEN PEN SNAPS, LEAVE IN INK FOUR OR FIVE SECONDS AND—IT IS FILLED

Do not be afraid to press trigger hard. As ink does not readily adhere to dry surface, it is advisable when the pen is new, to snap several times to insure maximum filling. After first filling, one snap is enough.

Use good fountain pen ink only, as this is a material aid to good writing and long service.

Clean pen occasionally—once a month at least. This is done by "snapping" pen several times in clean, clear, cold water.

This pen is guaranteed against defective workmanship. If anything is at all wrong, should Snapfil not give absolute service, return for our inspection. Snapfil "writes right always."

REPAIRS

We repair our own make of fountain pens only. In sending pens for repairs, always enclose name, address, instructions and remittance to cover, including return postage. Always empty fountain pens before sending them through mail.

PRICES

No.	New Gold Pens	Caps	Feeds	Barrels	Sections	Allowance for Old Gold Pen
2	\$1.25	\$0.40	\$0.40	\$0.75	\$0.50	\$0.20
3	1.50	.40	.40	.75	.50	.30
4	1.75	.50	.50	1.00	.60	.40
5	2.25	.60	.50	1.00	.60	.50
6	2.75	.70	.60	1.50	.75	.55
7	3.00	.70	.60	1.50	.75	.60

Chains and Pins.....	50c	Rubber Sacs.....	20c
Chains Only.....	20c	Presser Bars.....	50c
Pins Only.....	30c	Triggers.....	50c
Clips, Silver.....	25c	Cleaning and Adjusting.....	50c
Clips, Gold.....	50c		

Repairs are returned C. O. D. Parcel Post unless remittance is sent with pen.



SNAPFIL

THE PERFECT FOUNTAIN PEN

SNAPFIL

THE GENERAL MANUFACTURING CO.

Sioux City, Iowa

REG. U. S.
PAT. OFF.

Kaligraf

SMOOTH WRITING

The Right Pencil for Writing

Kaligraf is made from black and red, mottled hard rubber, highly polished, and because of the special materials used in its construction, will not dent or bend. Neither is it easily damaged by dropping—such as is usually the case with metal pencils.

Kaligraf is light weight—much more so than metal or other sharp-point pencils. Kaligraf is perfect mechanically, and every part is either riveted or screwed. Its construction is of the simplest, yet most efficient.

DIRECTIONS

When you receive Kaligraf, there are eleven reserve leads in the magazine, and one in the nozzle, ready to use. When more lead is needed raise the lever and push down once. This lever, in pushing lead out, locks against the ratchet, prevents lead from pushing back or coming out, and holds it firm and rigid. It works like an automobile jack.

TO FILL

- First—Unscrew nozzle.
- Second—Take one lead out of magazine.
- Third—Insert lead in UPPER END of nozzle.
- Fourth—Pull lever straight up.
- Fifth—Then push back plunger. (Lever must be straight up before plunger can be pushed back.)
- Sixth—Screw nozzle back on pencil.
- Seventh—Push down on lever once or twice, until you have sufficient lead out at point.
- Eighth—Kaligraf is ready to write.

Kaligraf is made in two sizes—both long and short—and six styles. The above illustrations are actual size of larger pencil; all sizes come with clip, without clip, or with ring. The long style has eraser.

ALL STYLES AND SIZES, \$1.50 EACH

EXTRA LEADS AND ERASERS

12 leads in tube (soft, medium or hard).....	\$.15
12 tubes in box.....	1.80
12 leads in tube (red, blue, green, indelible)..	.25
12 tubes in box.....	3.00
6 erasers in box.....	.15
12 boxes in carton.....	1.80

REPAIR PARTS*FOR KALIGRAF

Rubber barrel	\$.50
Point end complete.....	.25
Knob complete25
Filling device complete.....	.75
Clip25

No. K1
(Actual
size)

No. K1
(Actual
size)

Kaligraf

THE GENERAL MANUFACTURING CO.
SIOUX CITY, IOWA