

IMPORTANT INSTRUCTIONS

SHEAFFER'S FOUNTAIN PEN

FIG. 1



To properly fill a fountain pen, entirely submerge the point in fluid to "A," as in figure 1.

1. Snap the lever shut and leave in fluid five seconds.

FIG. 2



If pen is submerged, as in figure 2, it will fill partly with air.



Fill and expell the ink several times to flush the pen and moisten the feed and point.

When replacing the cap on your Sheaffer Fountain Pen hold pen with the point up. If the pen is held point down, the feed naturally becomes loaded with Skrip, when the cap is screwed on, an air-tight chamber is created. The Skrip runs down from the feed and forms a ring here and in the inner cap. When cap is removed this ring floods over and down around the barrel. Sheaffer pens do not leak. When applying cap make sure pen is held point up and you will have no trouble.

Sheaffer pens are made by experts, but cannot be guaranteed if taken apart or altered in any way. If any repairs are needed, take your pen to a reliable dealer or send to this factory for repairs. Mark your name and address plainly on the package and send remittance to cover cost of new parts and return postage.



RIGHT



WRONG

SKRIP—The Successor to Ink

Skrip is a clear, clean, fountain pen fluid that will not gum or clog your pen. Made in clear bright colors. Blue, green, red, violet or black. Use Skrip in your fountain pen and end all pen troubles. Ask your dealer about it.

W. A. Sheaffer Pen Co., Ft. Madison, Iowa, U.S.A.

Directions for Using

SHEAFFER'S

"LIFETIME" PENCIL



Turn the cap to the right to propel the lead to writing position. A quarter turn to the left draws the lead back into the barrel.

To Insert New Leads: Turn cap "A" to left as far as it will go. Pull out cap and remove eraser "C" from magazine "B". Take out lead and replace eraser and magazine in barrel. Insert new lead in tip at "D". The lead goes in easily two-thirds of the way and then a slight resistance is met. Keep pushing firmly until a solid resistance is met to force the lead in the carrier.



IMPORTANT

Before refilling the pencil with new lead turn the cap "A" firmly to the right until every particle of lead is expelled. The metal ejector or push rod will show at the tip "D" when the tip is cleared of lead.

Use Sheaffer leads in all pencils. Sheaffer leads are waxed to insure smoothness and better writing qualities. Black, hard, soft and medium. Colors: red, blue, and indelible. Sheaffer erasers with cup attached are inexpensive. Try them.

W. A. SHEAFFER PEN CO.

Ft. Madison, Iowa, U. S. A.

New York
80 5th Avenue

Chicago
506 Republic Bldg.

San Francisco
681 Market Street